

FPR-180/-SW/-GR/-BL

| Model | FPR-180 | FPR-180-SW/-GR/-BL |
|-------------------|-----------------|------------------------|
| Voltage | 12V DC | 24V DC |
| Power consumption | 13W | 17W |
| Mass | 380g | 380g |
| Connector type | 2P (1: +, 2: -) | 3P (1: +, 2: NC, 3: -) |

Third Angle Projection Units: mm








Low-angle Ring Lights / Low-angle Square Lights | FPR Series | FPQ Series


Even, diffused side lighting Low-angle, diffuse illumination enables characters and defects to be uniformly illuminated with no LED glare.

The FPQ Series provides even four-sided lighting for rectangular target inspection

When you need to illuminate a rectangular object such as a BGA or Quad Flat Pack uniformly, the corners of the object will be too close to the lighting if a round array is used. For this type of application, the rectangular FPQ Series is ideal.







Selectable lighting colors for optimal images

White, blue, and green colors are supported along with red. By selecting the illumination color to match the material and color of the work, a higher level of detection precision is possible.







Even diffuse light enables optimal imaging.

The image will vary depending on the distance between the workpiece and the light (light-workpiece distance = LWD) even when the light is the same.


It is key to successful image processing to find the best illumination according to the surface state and the content of inspection.

Inspection of engraved letters on metal surface (Lighting: FPR-136)










Imaging with LWD 230mm

With diffuse light illuminated from LWD 230mm, the entire area is imaged in bright field.



Illumination structure of FPR-100


The object is illuminated from a low angle by uniform diffuse light through the light conduction plate.



Examples of low-angle images Inspecting a BGA solder balls

Blue light is used to eliminate the background gold pattern and to enhance the visibility of the solder balls.

Lighting: FPQ-9



Blue


Inspecting SOP leads in embossed tape

There is minimal glare from the sides of the embossed tape.


Lighting: FPQ-48

Product Lineup Table

| Series | Model Name | Color | Power Consumption | Options | Dimension |
|--------|--------------------|-------|-------------------|---------|-----------|
| FPR | FPR-100 | • | 12V/6.0W | _ | 1 |
| | FPR-100-SW/-GR/-BL | 0/•/• | 24V/8.2W | _ | |
| | FPR-136 | • | 12V/9.3W | _ | 2 |
| | FPR-136-SW/-GR/-BL | 0/•/• | 24V/13W | _ | _ |
| | FPR-180 | • | 12V/13W | _ | 3 |
| | FPR-180-SW/-GR/-BL | 0/•/• | 24V/17W | _ | ٥ |





Dimensions (Unit: mm)





CCD Sensitivity Chart and Brightness Distribution FPR-100

A broad even distribution appears from approximately LWD 15 mm. If a high light intensity is not particularly required, evenness is maintained to approximately LWD 30 mm.









CCD Sensitivity Chart and Brightness Distribution FPQ-96

Diffused light from four sides provides a uniform area. Ideal for rectangular objects.

