

Digital Fiber Amplifier



# D3RF/D3IF Series

D3RF-T      D3IF-T  
 D3RF-TC 4    D3IF-TC 4  
 D3RF-TD

## Instruction Manual

Thank you for purchasing D3RF Series. We hope you are fully satisfied with this product and enjoy its performance. Carefully read this instruction manual and keep it for future reference.

Carefully read and understand the safety precautions before operation. The important information is provided to protect your health and property. Do not apply any other installing or operating procedure other than that described in this manual.

### Safety Precautions



It is dangerous to wire or attach/remove the connector with the power on. Make sure to turn off the power before operation.

Make sure to use the product with the protective cover attached and closed.

Installing in the following places may result in malfunction:

1. A dusty or steamy place.
2. A place generating corrosive gas.
3. A place directly receiving scattering water or oil.
4. A place suffered from heavy vibration or impact.

The product is not designed for outdoor use.

Do not use the sensor in transient state after power on (approx. 300ms).

Do not wire with the high voltage cable or the power line. Failure to do this will cause malfunction by induction or damage.

The sensor performance or digital display values may depend on the individual units or the condition of detected product.

This product is not an explosion-proof construction. Do not use the product under flammable, explosive gas or liquid environment.


Do not use the product in water.

Do not disassemble, repair, or convert the product.

Failure to do this may cause failure, fire, or electric shock. Operate within the rated range.

This product cannot be used as a safety device to protect human body.


### Input/Output Schematic




### Specifications

Model	Standard type	Moisture sensing type
Cable Type	1 output: D3RF-T (N/P) 2 output: D3RF-TD (N/P)	D3IF-T (N/P)
M8 Connector Type	1 output: D3RF-TC (N/P) 4 2 output: -	D3IF-TC (N/P) 4
Power source, voltage	12-24VDC±10%including a ripple	
Power consumption	Normal: 1 output: 864mW max.(36mA or less / 24V), 2 output: 936mW max.(39mA or less / 24V) Eco All: 1 output: 600mW max.(25mA or less / 24V), 2 output: 672mW max.(28mA or less / 24V)	
Response Time	1-HS:16µs / 2-FS:70µs / 3-ST:250µs / 4-LG:500µs / 5-PL:1ms / 6-UL:2ms / 7-EL:8ms	
Control output	1 output / 2 output, NPN / PNP Open collector 100mA / 30V or less Load current: 100mA or less, Residual voltage: 1.8V or less	
Output method	Light on / Dark on Switching type in the function	
Short-circuit protection	Incorporated	
Light source	Red LED (632nm)	IR LED (1,450nm)
Indicator light / Display	1 output: Output Indicator light: Orange (Ch 1) / 7 segment 8 digit display 2 output: Output Indicator light: Orange (Ch 1 / Ch 2) / 7 segment 8 digit display	-
Sensitivity setting	Teaching / Manual adjustment	
Timer function	OFF, On delay timer, Off delay timer, One-shot timer, On delay-off delay timer, On delay-one-shot timer	
Timer time	0.1ms~9.999s	
External input setting	Teach-in, Emitter stop, Synchronous, Counter reset (only for 2 output type)	
Output setting	1 output: Output 1 2 output: Output 2	-
Operating temperature / humidity	-25~+55°C/35~85%RH (No freezing and No condensation)	
Store temperature / humidity	-30~+70°C/35~85%RH (No freezing and No condensation)	
Shock resistance	10~55Hz Amplitude 1.5mm 2 hours for each direction of X, Y and Z	
Protective category	IP50	
Material	PC: Cover, Case	
Weight	Cable type: 71g (Including cordes) M8 Connector type: 25g	

### Dimensions



### Display/Indicator/Buttons



### Installing Amplifier

#### Mounting and Removing to/from DIN rail

**Mounting of Amplifier Unit**  
Hook the claw on the connecting side of fiber cable to the DIN rail. Then press down the hook until it locks.

**Removing of Amplifier Unit**  
Pushing the unit to the direction of , hold up the connecting side of fiber cable and remove the unit.

#### How to connect the fiber cables


Open fiber lock lever.  
Insert fiber into holes to stop.  
Return fiber lock lever until it stops.

#### CAUTION

With Coaxial reflection fiber, set single core fiber or white-lined fiber

#### How to use Fine fiber

Turn adapter cap anticlockwise completely, then appropriately insert the fiber.  
Cut the excess fiber with fiber cutter.



### Display and Buttons

#### Switching display

Display shows as follows according to its mode

Operating (RUN mode)	Setup	Teaching
It shows as example when it's actually detecting object. It goes to this mode after power up. Ex.) 200 100 Sensing Threshold level	It switches to this Setup mode by pressing "MODE" button over 3 seconds. Ex.) L--d L on Function Setup Value	It switches to this Teaching mode by pressing "TEACH" button over 3 seconds. Ex.) 2Pt 1Pt Mode of teaching

#### Buttons

Buttons work as follows according to its mode

Buttons	Operating (RUN mode)	Setup / Teaching
Adjust (+ UP)	Increase threshold level	Change the Setup function and mode of Teaching
Adjust (- DOWN)	Decrease threshold level	
MODE	Switch to Setup mode	Set the setup
TEACHING	Switch to Teaching mode	Execute Teaching


### Setup menu

Basic menu		
These are basic menu that to be setup before using. Please refer Expert menu for further setup function.		
Display	Menu	Function
L--d	Output mode	Switch Light ON and Dark ON
rESP	Response speed	Set response speed
dELY	Timer/Delay	Set Timer and Delay
EPrt	Expert mode	Enter to Expert mode (refer Expert menu)
rSEt	Initialize	Initialize setup to default
End	Exit	Exit setup mode

Expert menu		
These are menu for function that setup in detail. Expert menu is available from "Eprt" in Basic menu.		
Display	Menu	Function
0-rSt	Zero reset	Set main display to 0 (zero).
d.SP	Display mode	Set display mode for operating (RUN mode)
Eco	Eco mode	Set Eco mode
tUrN	Rotation	Rotate the display 180 degree
HYS	Hysteresis	Specify hysteresis percentage
PrCS	Detection mode	Set detection mode (edge/level)
cnt	Counter	Switch ON/OFF Counter and specify UP/DOWN direction
INPt	External input	Set function of external input
ASc	ASC	Set ON/OFF ASC (Automatic Sensitivity Control)
SPor	Emitter Power	Specify Emitter power
LoCl	Lock level	Specify level of Key Lock
SAvE	Save	Save the current setup
End EPrt	Exit	Exit expert menu
LoC	Lock	Lock buttons (refer useful function)


Teaching menu		
Threshold level can be set by these menu. Please refer "Teaching".		
Display	Menu	Function
2Pt	2 Point Teaching	Set the threshold at the center between with object and without object.
1Pt	1 Point Teaching	Set the threshold at minimum level that can detect object stably with.
tHru	Through Teaching	Set the threshold at around 90% of sensing level without object for through beam application.
ZonE	Zone Teaching	Set the threshold at around sensing level ± 10%.
Auto	Automatic Teaching	Set the threshold at the center between maximum and minimum level.
P-t	Percent Teaching	Threshold can be set any percentage.
0P-t	Zero % Teaching	Set the threshold at any percentage and execute zero reset.
End tEch	End of Teaching	Exit Teaching mode.

### Basic setup



### Setup Threshold manually

At RUN mode, press or then, threshold display blinks that shows it can be adjusted. Adjust the threshold by or . You can adjust upper and lower threshold when it's Zone Teaching mode.



## Teaching

Press TEACH button for 3 seconds.  
Choose Teaching mode by pressing or . Then, press to confirm. When Teaching is done, it goes back to RUN mode after the threshold blinks. You can refer current sensing level by pressing MODE while teaching.

**1. 2 point Teaching**  
Top  
Threshold is set at center of 1st and 2nd level.  
Teach twice with object and without object.

**2. 1 point Teaching (1)**  
Top  
Threshold is set at minimum level that enable stable detection.  
Good for long distance

**3. 1 point Teaching (2)**  
Top  
Teaching with only background for diffuse reflective mode. Threshold is set at minimum level that enable stable detection.

**4. Through Teaching**  
To  
Threshold is set at around 90% of sensing level.  
Good for detecting transparent object like Glass and Film.

**5. Zone Teaching**  
To  
Threshold is set at around sensing level  $\pm 10\%$ .  
Good for detecting object in the area specified.

**6. Automatic Teaching**  
Top  
Threshold is set at the center between maximum and minimum level. Good for teaching without stopping production line.

**7. Percent Teaching**  
Top  
You can set threshold at any percentage adjusted.  
By setting sensing level without object that block the beam as 100%, it can detect the level as relative percentage level.  
Re-Teaching can be done by single button action while RUN mode. Refer "Useful function Fitting in".

**8. Zero percent Teaching**  
Top  
Set any percentage adjusted to 0% as threshold.  
For diffuse reflective mode, set the sensing level with only background 0% and detect the level as relative percentage level.  
Re-Teaching can be done by single button action while RUN mode. Refer "Useful function Fitting in".

**Exit the Teaching mode**  
 By pressing TEACH button, it goes back to RUN mode.

## Expert mode

Setup parameters for further function.  
From **A** "Basic menu"

**4-1. Zero reset**  
Top  
0rSt off  
Set main display to 0 (zero)  
off No action †  
on Reset the main display  
Reset the sensing level shown on the main display to zero and shift the threshold shown on the sub display as much as the main display shifted. This function is not active when percent mode and edge detection mode.

**4-2. Display mode**  
Top  
di SP di 9  
Choose display mode from following three  
di 9 Digital mode † Ex.) 200 220  
Sensing level Threshold  
bAr Bar display mode Ex.) 11111  
Bar increases according to sensing level from right  
Pct Percent mode Ex.) 100. 110.  
Sensing level Threshold  
100% 110%  
"\_" means it's percentage

**4-3. Eco mode**  
Top  
Eco off  
Set Eco mode  
off No action †  
di SP Power off sub display (green) and darken main display (red).  
rESP Double emitting cycle.  
Actual response time will be doubled as well.  
ALL Power off sub display, darken main display and double emitting cycle. Actual response time will be doubled as well. Brightness of the display will be changed 20 seconds after the setup.  
Current consumption of "Eco ALL" will be 30% less than "Eco off".

**4-4. Rotation**  
Top  
turn off  
Rotate the display 180 degree  
off No action † Ex.) turn off  
on Rotate the display Ex.) 000000  
This is effective when you have to mount the sensor opposite direction.

**4-5. Hysteresis**  
Top  
HYS P 5  
Set Hysteresis percentage  
P 5 † Set from 1% to 40%  
P 1 ~ P 40  
1% 40%  
Set the hysteresis according to the condition. When it's unstable because of chattering, set bigger percentage. When to detect slight difference, set smaller percentage.

**4-6. Detection mode**  
Top  
PrCS Stnd  
Set Detection mode  
Stnd Detect by sensing level †  
hd\_f Detect UP edge  
hd\_l Detect Down edge  
Set filter level for edge detection  
F.Lt 1000 1,000 Hz † Faster  
F.Lt 200 200 Hz  
F.Lt 50 50 Hz  
F.Lt 20 20 Hz  
F.Lt 5 5 Hz Slower  
Edge detection mode:  
Detect changes of sensing level in a certain period.  
"Detect UP edge" : Detect the sensing level increasing  
"Detect Down edge" : Detect the sensing level decreasing  
\*Only Automatic Teaching can be executed when edge detection is activated.  
\*Percent display mode is unavailable when edge detection is activated.  
\*Only CH1 can be set Edge detection for the 2 output type (D3RF-TD).  
\*Hysteresis will be fixed to 1% when Edge detection is active.  
\*Edge detection won't work correctly when the sensing level is saturated or there is no light received.  
\*Filter to be "Slower" to detect sensing level that swings slower.

Choose the setup value by and . Define the setup by and go back to top of each menu. "†" is default value.

**4-7. Counter**  
Top  
cnt off  
Switch ON/OFF Counter and specify UP/DOWN direction  
off Counter OFF †  
uPc Set counting direction UP  
dnc Set counting direction DOWN  
Set counter value from 2 to 9999  
\*This function is only for "ch2" of the 2 output type (D3RF-TD).  
\*Threshold of CH1 is used for this function so please change to CH1 when you set threshold.

**4-8. External input**  
Top  
inPt rtch  
Set function of external input  
rtch External Teaching †  
tEst Emitting OFF input  
SYnc Synchronous input (hold the output)  
crSt Counter reset  
\*"crSt" is available only on the 2 output type (D3RF-TD).

**4-9. ASC**  
Top  
ASc off  
Set ON/OFF ASC (Automatic Sensitivity control)  
off ASC OFF †  
on Correction speed : Standard  
FASt Correction speed : Fast  
Hi Gh Correction speed : Fastest  
ASC:  
Adjust the threshold according to sensing level that is affected by environmental condition automatically.  
It corrects the threshold even when the sensing level changes quickly by cleaning up contamination. This is only for Through Teaching and Percent Teaching.  
ASC speed:  
"on" : adjust threshold "1" every three seconds  
"FAST" : adjust threshold "1" every one second  
"High" : adjust threshold "1" every 0.25 seconds  
\*Edge detection is unavailable when ASC is active.  
\*ASC is not available after Zone Teaching is executed.  
\*ASC is not available on CH2 output.

**4-10. Emitter power**  
Top  
SPor 1111  
Specify emitter power  
1111 Maximum †  
111 Three power level can be chosen  
11 Minimum  
Normally, maximum level is OK. Please lower the emitter power when sensing level is saturated.

**4-11. Lock level**  
Top  
LocL L 1  
Specify level of Key Lock  
L 1 Lock level 1 †  
Lock whole Keys (buttons)  
L 2 Lock level 2  
Lock Keys except Teaching button and buttons for switching percent display and standard level display. Only channel of the 2 output type (D3RF-TD) can be changed.  
You can Lock buttons actually by pressing 3 seconds at a time.  
\*External inputs are active on any Lock level.

**4-12. Save**  
Top  
SAvE no  
Save the current setup parameters  
no No action †  
YES Save the current setup

**End tEch** Exit Expert menu  
**tEch** Go to top of Expert menu

**Note** Some menu won't be shown depends on the setup. It's not a malfunction.  
\*Time of pressing buttons to activate not specified on this manual is 0.3 seconds.  
\*When the parameter value is ready to set, sub display will blink.  
\*Following parameters of the 2 output type (D3RF-TD) can be specified individually for Output 1 (ch1) and Output 2 (ch2). Other parameters are specified commonly.  
**Threshold, Output mode, Timer and its value, Teaching menu**

## Useful function

**Switch channel (only for the 2 output type D3RF-TD)**  
Press button then, the channel number will be blinking and switch to the channel.

CH1 display → 200 250 → CH2 → 200 100 → CH2 display  
← CH1 ←

Threshold of CH2 will be copied to CH1 under following condition after external teaching. This is useful when you want to set single threshold level to both CH1 and CH2.  
- ASC and Edge detection are inactive.  
- Teaching mode of CH1 is same as CH2.  
- Display is showing level of CH2.  
\*You can switch channel from any setup menu.

**Key Lock**  
Make the buttons unavailable to prevent operation mistake.  
Press for 3 seconds to Lock buttons at a time while RUN mode. Do same to cancel it..

Locked → Loc → Released → unLc  
You can choose a Lock level from two in "Expert mode 4-11.Lock level".

**Switching to RUN mode by single action**  
By pressing button for 3 seconds in setup menu while sub display is not blinking.

**Switching to percent display by single action**  
Press and buttons at a time then, the display switches to percent display.

Sensing level 5000 ↔ Percent display 100.  
You can setup this function at "Expert mode 4-2.Display mode" as well.  
Do same to get back to standard display mode.

**Fitting in (set sensing level to "100%" / "0%")**  
When "Percent Teaching" or "Zero % Teaching" is chosen in Teaching menu, you can set the sensing level to "100%" or "0%" by pressing and buttons at a time. This is effective when detection get unstable.

Before Fitting 90. → After Fitting 100.

## Error

Following are error messages when error occurred while Teaching. Please try again accordingly.

Err 1	Sensing level is not enough
Err 2	Sensing level is saturated
Err 3	Difference of sensing level between two points

## Option

**End unit**  
BEF-EB01-W190 (2 pieces)

Specification is subject to change without notice.  
Please contact following when you had any problems and questions regarding to this products.

Manufactured and sold by :  
**OPTEX FA CO., LTD.**  
600-8815 Kyoto, Shimogyo, Awata Chudoji 93, Japan  
TEL. +81-(0)75-325-2920 FAX. +81-(0)75-325-2921  
Website: <http://www.optex-fa.com>