

# FMC-B18 COLUMN FOR LIGHT CURTAINS

#### **GENERAL**

These mounting instructions contain information about the correct mounting of the column.

- The assembly of the FMC-B18 with the column rotation flange;
- The assembly of the FMC-B18 stand for mounting on the FMC-CB/FMC-CBL stand bottom;
- The correct mounting of the barrier on the column (rif. Normative ISO 13855 / EN999-2008);
- Alignment Emitter Receiver;
- Dimensions;

Please find detailed information about the function of the light curtains / light grids in the relevant mounting and wiring instructions.

## ASSEMBLY OF THE FMC-B18 WITH THE ROTATION FLANGE (Fig. 1)

• Assembly the rotation flange with the profile using the correct provided screws (as shown in figure 1).







Figure 1


8540946 Rev.1 4/6

#### ASSEMBLY OF THE FMC-B18 STAND WITH THE STAND BOTTOM; (Fig. 2)

- Mount the FMC-CB/FMC-CBL stand bottom on the floor (see mounting instruction for stand bottom).
- Loosen the three allen screws and remove the washers.
- Assembly the column to the stand bottom, centering the FMC-B column rotation flange with the guides of the FMC-CB/FMC-CBL stand bottom upper plate.
- Fix the column tightening the three allen screws and the washers.



#### **EXACT POSITION OF THE BARRIER ON THE COLUMN (Fig. 3)**



 You will find the exact position of the barrier in the table below (distance between the first light beam and the ground);
 (rif. Normative ISO 13855 / EN999-2008).

MODEL	2B	3B
	2 BEAMS	3 BEAMS
Н	400	300

Figure 3

8540946 Rev.1 5/6

#### BARRIER ASSEMBLY AND ALIGNMENT (Fig. 4)

- Put in the choosen slot the provided inserts (push to insert);
- Assembly the barrier to the column with the provides brackets;
- Perform leveling fine adjustments by means of the hexagonal nuts of the stand bottom (B).
- For an exact alignment of emitter and receiver, loosen the three allen screws **(C)** that fix the rotation flange and rotate the two columns until the barrier signal LEDS light on (ref. Technical manual).




Figure 4

### **DIMENSIONS (Fig. 4)**




Figure 5

8540946 Rev.1 6/6