



S62...M

**Background suppression** 

# INSTRUCTION MANUAL

#### **CONTROLS**

## **OUTPUT LED (yellow)**

The yellow LED ON indicates that the N.O. output is closed and the N.C. output is open.

#### STABILITY LED (green) (S62...M2/M3)

When permanently ON, the green LED indicates a normal operating condition where the received signal has a safety margin superior to 30% respect to the output switching value. The sensor is ready to function correctly (stability

# POWER ON LED (green) (S62...M0/M1)

The green LED ON indicates the powering status and the laser emission

#### **DISTANCE ADJUSTMENT TRIMMER (ADJ.)**

A 6-turn trimmer allows the background suppression distance adjustment through a mechanical variation of the optic triangulation angle.

The operating distance increases, rotating the screws in a clockwise direction. Please refer to the "SETTING" paragraph for acquisition or setup procedure

#### **POSITION INDICATOR**

This indicator presents a scale numbered from 1 to 6 that allows a precise adjustment of the suppression distance in the entire operating range. Please refer to the "SETTING" paragraph for use indications.

#### TIMER ADJUSTMENT TRIMMER (S62...M05/M15/M25/M35)

This control allows to vary the output delay deactivation from 0 to 1 sec. Please refer to "TIMER FUNCTIONS" paragraph for use indications.

#### DARK/LIGHT TRIMMER (S62...M01/M11-PN)

The LIGHT/DARK mode is selected using a mono-turn trimmer.

LIGHT MODE: clockwise rotation

DARK MODE: counter-clockwise rotation.

WARNING: the maximum mechanical rotation range of the trimmer is 240°. Do not force over of the maximum and minimum positions.

## **INSTALLATION**

The sensor can be positioned by means of the three housing's holes using two screws (M4x25 or longer, 1.5Nm max. tightening torque) with washers.


Various orientable fixing brackets to ease the sensor positioning are available (please refer to the general catalogue).

The operating distance is measured from the front surface of the sensor optics.


The M12 connector can be oriented at two different positions using the specific fastening spring and rotating the block of 180°.

#### CONNECTIONS


#### S62-PA-2/5...PN



#### S62-PA-2...PP/NN



# S62-PA-5...PP/NN (M12 connector)



## **TECHNICAL DATA**

	S62M0-PP/PN/NN	S62M1-PP/PN/NN	S62M2-PP/PN/NN	S62M3-PP/PN/NN	
Power supply:	10 30 VDC				
Ripple:	2 Vpp max.				
Consumption (output current excluded):	40 mA max.				
Outputs:	S62PP/NN: PNP or NPN N.A./N.C. 30 VDC / S62PN: NPN/PNP; 30 VDC max (short-circuit protection)				
Output current:	100 mA (overload and overvoltage protection)				
Output saturation voltage:	≤2 V				
Response time:	500 μs		1 ms	1,5 ms	
Switching frequency:	1 kHz		500 Hz	330 Hz	
Emission type:	RED (660 nm)		INFRARED (880 nm)		
Spot dimension:	6x6 mm (at 200 mm)	15x15 mm	(at 400 mm)	200x200 mm (at 2000 mm)	
Operating distance (typical values):	30300 mm	60600 mm	601200 mm	2002000 mm (recommended target 400x400mm)	
Adjustment:	Multiturn distance adjustment trimmer / Timer adjustment trimmer (S62M05/M15/M25/M35)				
DARK/LIGHT selection:	mono-turn trimmer (S62M01/M11-PN)				
Difference (90% white / 4% black):	< 8 %	< 12 %	< 25 %	< 30 %	
Hysteresis (90% white):	< 5 %				
Indicators:	OUTPUT LED (YELLOW) / STABILITY LED (GREEN)		OUTPUT LED (YELLOW)	/ POWER ON LED (GREEN)	
Operating temperature:	-10 55 °C				
Storage temperature:	-20 70 °C				
Dielectric strength:	500 VAC 1 min., between electronics and housing				
Insulating resistance:	>20 M $\Omega$ 500 VDC, between electronics and housing				
Ambient light rejection:	According to EN 60947-5-2				
Vibrations:	0.5 mm amplitude, 10 55 Hz frequency, for each axis (EN60068-2-6)				
Shock resistance:	11 ms (30 G) 6 shock for each axis (EN60068-2-27)				
Housing material:	ABS				
Lens material:	PMMA window; PC lens				
Mechanical protection:	IP67				
Connections:	2 m cable Ø 4 mm / M12 4-pole connector				
UL requirements:	they are inte	they are intended to be connected to a Class 2 transformer or class 2 power supply			
Weight:		90 g. max. cable vers. / 40 g. max. connector vers.			

#### **SETTING**


#### Suppression distance setting

## 1. Object detection

Position object to detect in front of the sensor at the distance required. Turn distance adjustment trimmer (ADJ) to minimum: yellow LED OFF and



Rotate trimmer in a clockwise direction until the yellow LED and green LED turn ON. Object detection condition (A status of position indicator)




# 2. Background suppression

Remove object and ensure that the background is in front of the sensor: vellow LED OFF and green LED ON.



Rotate trimmer in a clockwise direction until the yellow LED and green LED turn ON: background detection condition (B status of position indicator).



The trimmer reaches maximum level with yellow LED OFF if the background is outside the operating range.

Rotate trimmer in an anticlockwise direction until yellow LED turns OFF and green LED ON: condition where background is outside operating range (C status of position indicator).




#### 3. Setting and control


Rotate trimmer in an anticlockwise direction until the indicator reaches an intermediate point between position A and C.




If position A and C are close to each other, leave trimmer on position C. The sensor is now ready to function correctly and in stable conditions:



#### **DETECTION DIAGRAM**




## **DIMENSIONS**




# TIMER FUNCTION (S62...M05/M15/M25)

The timer function allows to adjust the output deactivation delay when the object is outside the detection area. The delay extends the output activation allowing the slower interface systems to detect shorter pulses.



The delay adjustment is carried-out manually using the Timer adjustment trimmer. Clockwise rotation increase the delay from 0 to a max. 1 sec. value.



## DECLARATION OF CONFORMITY

We Datalogic Automation declare under our sole responsibility that these products are conform to the 2004/108/CE and successive amendments.

Datalogic Automation warrants its products to be free from defects Datalogic Automation will repair or replace, free of charge, any product found to be defective during the

warranty period of 36 months from the manufacturing date.

This warranty does not cover damage or liability deriving from the improper application of Datalogic Automation products

#### DATALOGIC AUTOMATION

Via Lavino 265 - 40050 Monte S.Pietro - Bologna - Italy

Tel: +39 051 6765611 - Fax: +39 051 6759324

DATALOGIC AUTOMATION cares for the environment: 100% recycled paper.

DATALOGIC AUTOMATION reserves the right to make modifications and improvements without prior notification.

© 2007 - 2012 Datalogic Automation - ALL RIGHTS RESERVED - Protected to the fullest extent under U.S. and international laws. • Copying, or altering of this document is prohibited without express written consent from Datalogic Automation. Datalogic and the Datalogic logo are registered trademarks of Datalogic S.p.A. in many countries, including the U.S.A. and the E.U.

826002874 Rev.F