


S50-PH/MH SERIES INSTRUCTION MANUAL



S50-PH/MHB01/C01/F01			S50-PH/MHG00		
BROWN	1	▶ 10 30 Vdc	BROWN		10 30 Vdc
WHITE	2	N.C. OUTPUT	WHITE	2	TEST +
BLACK	4	N.O. OUTPUT	BLACK	4	NOT USED
BLUE	3	0 V	BLUE	3	- 0 V

The connections are compliant to the EN 60947-5-2 standard.

DIMENSIONS



TECHNICAL DATA

CONNECTIONS

M12 CONNECTOR

SETTING

Setting of S50-PH/MH...B01

Position the sensor and reflector on opposite sides. Turn the sensitivity trimmer to the maximum position.

Moving the sensor both vertically and horizontally, determine the power ON and OFF points of the OUTPUT LED and then mount the sensor in the middle of the points defined.

If necessary reduce sensitivity in order to detect very small targets. In order to improve alignment, repeat the given procedure whilst progressively reducing the sensitivity.

Setting of S50-PH/MH...F01/G00

Position the sensor and reflector on opposite sides.

Turn the sensitivity trimmer to maximum: moving the sensor both vertically and horizontally, determine the power ON and OFF points of the OUTPUT LED and then mount the sensor in the middle of the points. defined

If necessary, reduce sensitivity using the trimmer, in order to detect very small targets. In order to improve alignment, repeat the procedure detailed above whilst progressively reducing the sensitivity.

Setting of S50-PH/MH...C01

Turn the sensitivity trimmer to minimum: the OUTPUT LED is OFF Position the target to detect in front of the sensor.

X MIN

Turn the sensitivity trimmer clockwise until the OUTPUT LED turns ON (Target detected state, pos.A). Remove the target, the OUTPUT LED turns OFF.

Turn the sensitivity trimmer clockwise until the OUTPUT LED turns ON (Background detected state, pos.B).

The trimmer reaches maximum if the background is not detected.

Turn the trimmer to the intermediate position C, between the two positions A and B.

TEST FUNCTION (S50-PH/MH...G00)

The TEST+ input can be used to deactivate the emitter and verify that the system is operating correctly.

The receiver output should switch when the test is activated while the beam is uninterrupted.

CONTROLS

OUTPUT LED (S50-PH/MH...B01/C01/F01/)

The vellow LED ON indicates that the N.O. (normally open) output status is closed.

POWER ON LED

The green LED indicates that the sensor is operating.

TRIMMER (S50-PH/MH...B01/C01/F01)

The trimmer can be used to adjust sensitivity: the operating distance increases turning the trimmer clockwise.

WARNING: The trimmer rotation is limited to 270° by a mechanical stop. Do not apply excessive torque when adjusting (max 40 Nmm).

INSTALLATION

S50-PH: The sensor can be fixed by means of the M18x1 threaded body through a Ø 18 mm hole, using the specific washer and the two CH.24 nuts enclosed (1.5 Nm maximum tightening torque). Amongst the various possible solutions, we suggest to choose the combination that offers the best visibility of the signalling LEDs and the easiest access to the trimmer.

22 mm nuts, h=8 mm, (2 Nm maximum tightening torque) are available to guarantee an improved torgue.

S50-MH: The sensor can be fixed by means of the M18x1 threaded body through a \emptyset 18 mm hole, using the specific washer and the two CH.24 nuts enclosed (22 Nm maximum tightening torque).

Various orientable fixing brackets for both plastic and metallic versions are available to ease sensor positioning (please refer to the accessories listed in the general catalogue).

The operating distance is measured from the front surface of the sensor lens

	S50-PH PLASTIC VERSIONS	S50-MH METAL VERSIONS			
Power supply:	10 30 Vdc limit values				
Ripple:	2 Vpp max.				
Current consumption	35 mA max. (mod.B01/C01/F01)				
(output current excluded):	30 mA max (mod.G00)				
Outputs:	N.O. and N.C.; PNP or NPN (short-circuit protection)				
Output current:	100 mA max.				
Output saturation voltage:	2 V max.				
Response time:	333 µs				
Switching frequency:	1.5 kHz				
Indicators:	OUTPUT LED (YELLOW) (mod.B01/C01/F01) POWER ON LED (GREEN)				
Setting:	sensitivity trimmer (mod.B01/C01/F01)				
Operating mode:	LIGHT mode on N.O. output / DARK mode on N.C. output (mod.C01) DARK mode on N.O. output / LIGHT mode on N.C. output (mod.B01/F01)				
Operating temperature:	-10 50 °C				
Storage temperature:	-25 70 °C				
Insulating strength:	500 Vac 1 min., between electronics and housing				
Insulating resistance:	>20 M Ω 500 Vdc, between electronics and housing				
Operating distance (typical values):	B01: 0.19 m on R2 reflector				
	C01: 025 cm				
	F01/G00: 050 m				
Emission type:	RED LASER: Class 1 EN 60825-1 (1994) (mod.B01/C01/G00) Class II CDRH 21 CFR PART 1040.10 (mod.B01/C01/G00)				
Anabiant linkt as is sting.	Max. power \leq 1 mW; Pulse = 4.5 μ s; λ = 630680 nm; Frequency =25 kHz				
Ambient light rejection: Vibrations:	According to EN 60947-5-2				
Shock resistance:	0.5 mm amplitude, 10 55 Hz frequency, for every axis (EN60068-2-6)				
	PBT	(30 G) 6 shock for every axis (EN60068-2-27)			
Housing material: Lens material:		PBT Nickel-plated brass PMMA			
Mechanical protection:					
Connections:	IP67 Metal versions type 1 enclosure				
Weight:	2 m cable Ø 4 mm / M12 - 4 pole connector 75 g. max. cable vers. /25 g. max. conn. vers. 110 g. max. cable vers. /60 g. max. conn. vers.				
Weight.	15 g. max. cable vers. /25 g. max. com. vers.	TTO Y. Max. Cable Vers. 700 Y. Max. COM. Vers.			

DECLARATION OF CONFORMITY

WA DATALOCIC ALITOMATION de ole responsibility and successive

to be free from

e of charge, anv product found to be defective during the warranty period of 36 months from the manufacturing date.

This warranty does not cover damage or liability deriving from the improper application of DATALOGIC AUTOMATION products.


DATALOGIC AUTOMATION

Via Lavino 265 - 40050 Monte S.Pietro - Bologna - Italy Tel: +39 051 6765611 - Fax: +39 051 6759324 www.automation.datalogic.com e-mail:info.automation.it@datalogic.com

DATALOGIC AUTOMATION per l'ambiente: 100% carta riciclata. DATALOGIC AUTOMATION si riserva il diritto di apportare modifiche e/o miglioramenti senza preavviso

Datalogic and the Datalogic logo are registered trademarks of Datalogic S.p.A. in many countries, including the U.S.A. and the E.U.

826001684 Rev.F © Copyright Datalogic 2007-2011



that these products are conform to the 2004/108/CE amendments.				
WARRANTY DATALOGIC AUTOMATION warrants its products to defects.				
DATALOGIC AUTOMATION will repair or replace, free				